

WHITELINE

KTA158 – S197 Mustang Rear Lower Control Arms - Fixed

Kit Includes:

- Control Arms - 2

Tools Required:

- 1 1/8 inch wrench - 2
- 18mm Wrench or Socket
- Flat Blade Screw Driver

WARNING: Whiteline Products are designed for easy installation however professional installation by a Whiteline Performance Center is recommended. Please drive carefully and accustom yourself to the improved handling characteristics of the vehicle.

1. Lift the vehicle and place jack stands under the rear axle, and then remove both rear wheels.
2. Using a flat blade screwdriver, detach the brake cable from the caliper and slide the brake cable out of the control arm. Repeat on both sides.
3. Using an 18mm wrench or socket, remove both control arm bolts and remove the control arm.

NOTE: Do not remove more than one control arm at a time.

4. Install the control arm using the factory bolts with the wider bushing towards the rear of the car and the thicker side of the rear bushing facing the center of the car. Tighten all mounting bolts to 130 ft./lbs.
5. Repeat steps 2 through 4 on the opposite side.
6. Re-install the brake cables, then install the wheels and tires.
7. Lower the vehicle to the ground and check that all fasteners are properly torqued.
8. Recheck all fastener torque after initial 100 miles of driving.

For specialist assistance in North America:

Website: www.WhitelineUS.com

Email: Support@WhitelineUS.com

Phone: (909) 476-2860

All other countries please email Support@Whiteline.com.au