Japper lighting

575 LED Installation Guide

Step 1: Install new headlamps using original bucket and trim rings.



Step 2: Plug new H4 adapter into your original headlamp socket. Note: the difference between high beam and low beam.



Step 2 Continued: Low beam will have 3 pins on the H4 Connector and high beam will only have 2 pins.

Note: If you only have 2 pins on your low beam, check the part numbers to identify low and high: H11H4AD-L = LOWH11H4AD-H = HIGH

Classic Halos: There are many different options for wiring up halos.

Halo Color	Wire Color	Functionality
White	Red +	Day-Time Running
Amber	Yellow +	Turn Signal (Switchback)
	Black -	Ground

Modern Halos: You will NOT have a yellow wire.

HDR Halos: You may have additional wires that are used for dim/bright functionalities. A wiring guide is labeled on the Halo LED Driver.

Pro-Tip: Wire your White Halos (**Red Wire**) to your ignition to have your halos come on as soon as you turn your key!

www.dapperlighting.com • (833)-DAPPER-1 • support@dapperlighting.com