# **Mustang Front or Rear Speaker Upgrade**

Installation Instructions KA-6x8-SPEAKER

#### **Contents:**

2EA 6x8 Speaker – RW0868C

#### **Tools required:**

7mm Nut Driver Panel Removal Tool Pick Tool Torx® T25 Driver Torx® T30 Socket Ratchet

### **Front Speakers**

- 1. Using your hand pull and remove the triangle shaped trim piece from the top of the door. Fig. 1
- 2. Using a pick tool remove the screw cover from behind the door handle. Remove the Torx®T-30. Fig. 2





- 3. Using a panel removal tool pry the switch plate away from the door panel and disconnect wiring. Fig. 3
- 4. Remove the 7mm screw located behind the switch plate. Fig. 4





### Mustang Front or Rear Speaker Upgrade

Installation Instructions KA-6x8-SPEAKER

- 5. Remove the eight 7mm screws around the perimeter of the door panel. Fig. 5
- 6. Remove the plastic screw cover behind the door release lever. Remove Torx®T-30.
- 7. Lift straight up on door panel to separate it from the metal. With the door panel loose snap the door release lever out of the door panel and pass it through the hole leaving the linkage attached to the lever. Disconnect all factory wiring from the door and remove panel. Fig. 6





- 8. Remove the factory speaker using a Torx® T20 driver and disconnect wiring. Fig. 7
- 9. Reconnect wiring to the upgrade speaker and reinstall using the factory screws. Fig. 8
- 10. Reinstall all previously remove parts in reverse order and repeat process on other door.





## Mustang Front or Rear Speaker Upgrade

Installation Instructions KA-6x8-SPEAKER

### **Rear Speakers**

- 1. Remove the sill plate along the bottom of each door opening. Fig. 9
- 2. Remove the lower rear seat cushion by pushing the front edge back and then lifting up.
- 3. Release and fold down the rear seat backs.
- 4. Remove the three plastic retainers that secure each quarter panel cover. One retainer is above the floor pan and the other two are located in the pass through area between the cabin and the trunk. Fig. 10





- 5. Pull loose the rear quarter panel covers and remove from the car. Fig. 11
- 6. Remove the four plastic retainers securing the rear deck cover. Fig. 12





- 7. Pull the rear deck cover away from the rear window and remove from car. Fig. 13
- 8. Using a ratchet and a Torx® T20 socket, remove the factory speakers and disconnect wiring. Fig. 14
- 9. Reconnect wiring to the upgrade speaker and reinstall using the factory screws.
- 10. Reinstall all previously removed parts in reverse order.





4-1-09 Page 3 of 3